

Instructions for Fitting GS Tackle Deeper Mount v1 to Actor Plus Bait Boat

The Deeper mount comes with all fixings required, this consists of the following:

- 1 x Mounting Body
- 1 x Sliding Collar
- 1 x Sliding Tube (Carbon Fibre or Aluminium, both shown in picture but only 1 supplied)
- 1 x Tube insert (fits inside of the Carbon or Aluminium Tube)
- 1 x M4x22mm Countersunk Screw
- 1 x M4 Square Nut
- 1 x M5x75mm Countersunk Screw
- 1 x M5 Solid Countersunk Washer



When receiving the kit you may find it partly assembled, with the sliding parts being ready to mount to the Deeper (not supplied).

Mounting Instructions :

The main body of the mount is designed to be mounted over the standard hook release system (this means you can no longer utilise the hook dropper, if the button is pressed nothing will happen and the mount won't be affected)

Once fitted the screw will pass through this hole indicated :



Please check there is no obstructions in the hole, if there is please screw the M4x22mm Screw into the hole – this should push out any moldings / rubbish from the hole.

Next slide the Main Body of the mount over the hook release :



Slide it on until its fully seated against the hull of the boat, visually check the countersunk hole is aligned with the hole in the hook release. Due to some molding variations of the hook release the body was designed to be tight up against the body – therefore there maybe up to ½ hole misalignment.

Push the M4x22mm screw into the hole by hand until it doesn't go any further, you normally then need to screw the screw through the hook release. Once the screw is nearly fully inserted, lick a finger and place the M4 Square nut on it, then place it into the square cutout on the other side of the mount.



Now take a suitable 2.5mm Allen Key (optionally supplied) and turn the countersunk screw whilst applying light pressure still to the nut :



IMPORTANT NOTE –

Do NOT overtighten the screw or you can damage the mount, also do not tighten the screw without the mount being fitted to the boat.

The short side of the allen key is more than sufficient to tighten the bolt – as pictured.

Mounting the Deeper :

Take the supplied M5x75mm Countersunk Screw and slide the M5 Solid Countersunk Washer on, next take the thin walled plastic tube and carefully slide / screw this all the way up the threads (this just helps centre the tube)

Once complete slide the tube (Aluminium or Carbon) on, then slide the sliding collar on (please check orientation, the lip or largest part is at the top of the screw)

Next take your deeper and check the middle top screw hole is clear of debris –



Next take the 3mm Allen key and tighten the assembly into the Deeper, holding the deeper with one hand and the allen Key with the other.

Again I would recommend to only use the short end of the allen key here,

Overtightening could damage the carbon tube, or even damage the threads in the deeper.



Once connected the sliding pieces can be left built up on the Deeper – for quick connection.



To fit the Deeper simply hold the sliding piece, and angle the deeper approx. 45 degrees, slide the tube through the opening of the bracket :



Then lower the sliding piece down whilst aligning the tab into the cut-out, press the sliding piece down (very slight click is felt).

To remove the deeper, it's a reverse order – put a finger into the slot to lift the tab up



Then slide it up, and angle it again to remove.



Thank you for your purchase, any problems please do not hesitate to contact me.